

“POT SHOT”



A uniquely formulated deodorizer that eliminates smells in sumps, pits, toilets and holding tanks.

Applications: Airlines, buses, outhouses, R.V's and any other area where odour of human waste is a problem.

Directions/Dilutions: For portable toilets: Add 10 ml to initial charge of water. Repeat each time tank is dumped. Add 10 ml if tank is not emptied weekly. R.V, marine, airplane, bus holding tanks: add 10 ml. Add through toilet bowl and repeat each time emptied. If tank is not dumped weekly use 10ml weekly as maintenance dose. Stationary toilets add 40 ml as initial dosage. 10 ml ounces weekly to maintain. Natural pit toilets add 30 ml to 1 litre of water and pour in as initial charge. 10 ml per 1 litre of water and pour in weekly to maintain.

Laboratory Analysis:

Appearance: Blue liquid
Odour: Cherry scent
Solubility: Water soluble
Flammability: Non flammable



Packaging: 205 litre drums
20 litre pails
4 x 4 litre containers



For further information consult the material safety data sheet and label.

Visit us at our website www.chemfax.com